

RELEASE NOTES

iZ[®] TECHNOLOGY CORPORATION END USER SOFTWARE LICENSE AGREEMENT

NOTICE: READ THIS BEFORE USING THE SOFTWARE PROGRAM INSTALLED ON THIS PRODUCT.

BY USING THE SOFTWARE PROGRAM AS PART OF THIS PRODUCT YOU AGREE THAT YOU HAVE READ THIS LICENSE, THAT YOU ARE BOUND BY ITS TERMS AND THAT IT IS THE ONLY AGREEMENT BETWEEN YOU AND iZ TECHNOLOGY CORPORATION REGARDING THE PROGRAM AND DOCUMENTATION. USE OF THE SOFTWARE INDICATES YOUR ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT ACCEPT THESE TERMS, YOU MUST DISCONTINUE USE OF THE PRODUCT AND CONTACT THE MERCHANT PROVIDING YOU THE PRODUCT FOR A REFUND.

PLEASE NOTE THAT YOU MAY NOT USE, COPY, MODIFY OR TRANSFER THE PROGRAM OR DOCUMENTATION OR ANY COPY, EXCEPT AS EXPRESSLY PROVIDED IN THIS AGREEMENT.

LICENSE: This program and documentation are licensed, not sold to you. You have a non-exclusive and nontransferable right to use the enclosed program and documentation. This program can only be used on the single device it came installed on, located in the country to which this software is legally exported. You agree that the program and documentation belong to iZ Technology and its licensors. You agree to use your best efforts to prevent and protect the contents of the program and documentation from unauthorized disclosure or use. iZ Technology and its licensors reserve all rights not expressly granted to you.

LIMITATIONS ON USE: You may not rent, lease, sell or otherwise transfer or distribute copies of the program or documentation to others. You may not modify or translate the program or the documentation without the prior written consent of iZ Technology. You may not reverse assemble, reverse compile or otherwise attempt to create the source code from the program.

LIMITED TRANSFER: You may only transfer this program as incorporated in the device in which the program was delivered to you, and only in connection with your transfer of the device itself. You may not retain any copies and you may not sublicense the program, and except as described above, you may not assign, delegate or otherwise transfer this license or any of the related rights or obligations for any reason. Any attempt to make any such sublicense, assignment, delegation or other transfer by you shall be void.

COPYRIGHT: The program and related documentation are copyrighted. You may not copy any documentation. You may not copy the program. Any and all other copies of the program made by you are in violation of this license.

OWNERSHIP: You agree that you neither own nor hereby acquire any claim or right of ownership to the program and documentation or to any related patents, copyrights, trademarks or other intellectual property. You own only the device, magnetic or other physical media on which the program and related documentation are recorded or fixed. iZ Technology and its licensors retain all right, title and interest in and to the documentation and all copies and the program recorded on the original media and all subsequent copies of the program at all times, regardless of the form or media in or on which the original or other copies may subsequently exist. This license is not a sale of the original or any subsequent copy.

WARRANTY DISCLAIMER: iZ TECHNOLOGY AND ITS LICENSORS PROVIDE THE PROGRAM AND THE DOCUMENTATION "AS IS" WITHOUT WARRANTY OF ANY KIND EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT.

Some provinces, states or countries do not allow the exclusion of implied warranties, so the above exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from province to province, state to state and country to country.

The copy of the software may have been delivered to you bundled with third party software applications not owned by iZ Technology. SUCH THIRD PARTY SOFTWARE IS PROVIDED TO YOU "AS IS" AND WITHOUT WARRANTY OF ANY KIND BY iZ TECHNOLOGY EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. Your rights and warranties, if any, regarding such third party software are governed by such third party's own end user license agreement and not by iZ TECHNOLOGY.

LIMITATION OF REMEDIES: IN NO EVENT WILL iZ TECHNOLOGY OR ITS LICENSORS BE LIABLE FOR ANY INDIRECT DAMAGES OR OTHER RELIEF ARISING OUT OF YOUR USE OR INABILITY TO USE THE PROGRAM OR ANY THIRD PARTY APPLICATIONS INCLUDING, BY WAY OF ILLUSTRATION AND NOT LIMITATION, LOST PROFITS, LOST BUSINESS OR LOST OPPORTUNITY, OR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF SUCH USE OR INABILITY TO USE THE PROGRAM OR ANY THIRD PARTY APPLICATIONS, EVEN IF iZ TECHNOLOGY AND ITS LICENSORS OR AN AUTHORIZED iZ TECHNOLOGY DEALER, DISTRIBUTOR OR SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

Some provinces, states or countries do not allow the exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

GOVERNING LAW: This license will be governed by the laws of Canada.

WHAT'S NEW IN VERSION 1.1.1?

FRONT PANEL LOCK

The front panel can now be locked, so that ADA settings are not changed accidentally.

WHAT'S NEW IN ADA II WITH VERSION 1.1?

LARGER DISPLAY

ADA II has a larger 10.1", higher-resolution display. The user interface is easier to use, with more buttons on fewer screens. The Main Screen shows both the A/D and the D/A meters.

NEW FRONT PANEL

ADA II has a new fingerprint-resistant front panel with a high-contrast white LED ring-lit power switch.

AES MULTICHANNEL CARD SUPPORT

ADA II supports the 24-channel transformer balanced AES card.

PROTOOLS SAMPLE RATE ERROR INDICATOR









ADA II has a new ProTools sample rate error indicator.

FUTURE SOFTWARE UPDATES

ADA II is compatible with all new ADA software upgrades. (ADA I software will not be upgraded past 1.0.1.)

INSTALLING VERSION 1.1.1 SOFTWARE ON YOUR ADA

Since version 1.1.1 is a free upgrade from version 1.1, you can download the file [ADA_v1.1.1.rar](#) directly from the iZ web site. This file can be copied to a USB drive or a network drive and then installed as follows:

- 1 Select **UPDATE SOFTWARE** from the **SYSTEM MENU**, then choose from the following options:
 - **WEB:** If your ADA is connected to the internet, and you already have version 1.1 or later installed, you can download the 1.1.1 software directly from the iZ web site.
 - **N:** If you are installing the 1.1.1 software upgrade from a network drive, use the , , and  keys to locate the file [ADA_v1.1.1.rar](#). Then press .
 - **E:** If you are installing the 1.1.1 software upgrade from a USB drive connected to your ADA, use the , , and  keys to locate the file [ADA_v1.1.1.rar](#). Then press .
- 2 Answer **YES** to the **INSTALL VER 1.1.1?** prompt.
- 3 When prompted, power off ADA and reboot.
- 4 When ADA has finished rebooting, it will start up in the new version.

ADA SYSTEM DRIVE RECOVERY PROCEDURE



This procedure will erase all data on your system drive.

- 1 Plug a PC USB keyboard into a USB port on ADA.
Turn on ADA, and at the POST screen (first screen) press the [DEL] key to enter CMOS Setup.
In Advanced BIOS Features / Boot Sequence, change the settings on your ADA unit so that the USB drive comes first in the boot sequence, and save the changes.
- 2 Plug the **izOS Software Recovery USB Drive** into a USB port and reboot ADA.
- 3 When the System Rescue screen appears, press **ENTER** at the **ENTER TO BOOT** prompt.
- 4 After the operating system software has loaded, follow the instruction to type **'YES'** and press **ENTER** to proceed with system recovery.
- 5 **WARNING: ALL DATA ON THE SYSTEM AND ARCHIVE PARTITION WILL BE LOST** will appear as a final warning, with the instruction to **TYPE 'YES' AND PRESS ENTER TO PROCEED**. At this prompt, type **'YES'** and press **ENTER** to proceed with system recovery.



If you press **ENTER** without typing **'YES'**, you will see the message **REBOOT, AND CHANGE THE CMOS SETTINGS TO THE DEFAULT BOOT ORDER, REMOVE THE DISK, AND REBOOT. END OF AUTORUN SCRIPTS, PRESS <ENTER> TO CONTINUE**. At this point, you can restart the recovery process by pressing **ENTER** and then typing **'EXIT'** at the **/ROOT %** prompt, or you can cancel the recovery process by removing the recovery USB drive, rebooting and changing the CMOS settings back to the original boot sequence.

- 6 You will see the message **PLEASE WAIT, THE RECOVERY PROCESS MAY TAKE SEVERAL MINUTES. FORMATTING PART 1 OF 1**. The software is loaded to ADA's system drive in this phase. When this phase is complete, you will see some statistics similar to the following:

2127152+0 records in
2127152+0 records out
2178203648 Bytes (2.2 GB) copied, 439.218 s, 5.0 MB/s
- 7 When the **RECOVERY COMPLETE** message appears, follow the instruction to **REBOOT, AND CHANGE THE CMOS SETTINGS TO THE DEFAULT BOOT ORDER, REMOVE THE DISK, AND REBOOT**. After this reboot, ADA software will start automatically.

Update ADA to the most current software version if required.

MENU STRUCTURE IN VERSION 1.1.1

Here is the ADA menu structure for Version 1.1.1.

SYSTEM MENU ▼

- SET TIME & DATE
- UPDATE SOFTWARE
- UPDATE CONFIG
- HELP ▼
 - RELEASE NOTES
 - MANUAL

SYNC MENU ▼

- MADI COAX/OPT IN
- VIDEO FORMAT
- DIG 2-CH FORMAT
- IGNORE AES FLAGS
- SYNC REF OUTPUT

I/O MENU ▼

- ANALOGUE LEVELS
- DIG IN FORMAT
- MADI SETTINGS ▼
 - SAMPLE RATE IN
 - EMPHASIS IN
 - EMPHASIS OUT
 - 96 kHz FRAMING
 - 192 kHz FRAMING
 - 192 kHz CHANNELS
 - INSTALL FIRMWARE

AES SETTINGS ▼

(IF AES CARD PRESENT)

- SYNC CHNL PAIR
- SAMPLE RATE IN
- EMPHASIS IN
- EMPHASIS OUT
- MULTI-CHNL TYPE

ADAT SETTINGS ▼

(IF ADAT CARD PRESENT)

- ADAT IN CLOCK
- ADAT IN WIDTH
- ADAT IN SMPL PT
- ADAT OUT WIDTH
- ADAT OUT USERBIT
- FACTORY DEFAULTS

PREFERENCES MENU ▼

- PEAK HOLD TIME
- CLIP HOLD TIME
- NOISE FLOOR
- SCRN-SAVER DELAY
- SCRN-SAVER MODE
- NETWORK PREFS ▼
 - INTERFACE PREFS ▼
 - HOST NAME
 - DHCP SERVER
 - LOCAL IP ADDRESS
 - SUBNET MASK
 - GATEWAY
 - PRIMARY DNS
 - SECONDARY DNS
 - SMTP HOST
 - SERVER PREFS ▼
 - NETWORK PROTOCOL
 - SERVER IP ADDR
 - SERVER NAME
 - EMAIL PREFS ▼
 - COMPANY NAME
 - LOCATION
 - REPLY EMAIL

DIAGNOSTICS MENU ▼

- SHOW AUDIO LEVEL
- AUDIO REF LINE
- SHOW CURSOR
- PING IP ADDRESS
- CONFIGURE DEBUG
- SAVE DEBUG
- EMAIL DEBUG
- FACTORY SETTINGS
- INSTALL PREV VER
- SUPPORT EMAIL
- SALES EMAIL