

SYSTEM MENU ▼

SYSTEM INFO ▼

- RADAR SOFTWARE VER
- SERIAL NUMBER
- RECORDING ENGINE
- SYNC ENGINE
- INSTALLED RAM
- CPU TYPE
- CPU SPEED
- IP ADDRESS
- MAC ADDRESS
- ETHERNET TYPE
- ANALOG I/O
- DIGITAL I/O 1
- DIGITAL I/O 2
- DIGITAL I/O 3
- IDE 0 MASTER
- IDE 1 MASTER
- SCSI ID 0
- SET TIME & DATE
- SET SERIAL NUM
- UPDATE SOFTWARE

DISK MENU ▼

- MOUNT/UNMOUNT
- SHOW DISK SPACE
- RECLAIM SPACE
- MAKE PORTABLE
- ERASE ALL AUDIO
- INIT DISK
- DISK MODE
- 24 TRKS AT 192K
- SEAMLESS 64K
- CLONE RADAR DISK
- DISK NOTES
- ENABLE DISK ID

SYNC MENU ▼

TC SETTINGS ▼

- TC FORMAT
- TC RATE
- SMPTE LOCK SPEED
- FREEWHEEL TIME
- STATIC TC OUT
- CHASE MODE
- SHOW SYNC DRIFT
- SYNC THRESHOLD
- CHASE ON POWERUP
- SYNC REFERENCE

RADARLINK ▼

- ENABLE/DISABLE
- RADARLINK SOLO
- RADARLINK ID

MACHINE CONTROL ▼

- ENABLE/DISABLE
- SELECT TYPE

9-PIN SETTINGS ▼

- DEVICE ID
- 9-PIN CHASE MODE
- TRACK ARM MODE
- VARISPEED MODE
- SHUTTLE-0 MODE
- TC OUT MODE-CUE
- TC OUT MODE-PLAY

MMC SETTINGS ▼

- DEVICE ID
- SYNC REF OUTPUT
- LOST SYNC IN REC

I/O MENU ▼

I/O ROUTING ▼

- INPUT ROUTING
- OUTPUT ROUTING
- RESET ROUTING
- DIG 2-CH ROUTING
- DIGITAL INPUTS
- 8-BUS MODE

ANALOG I/O LEVEL

- DIG IN FORMAT
- DIG I/O SDQ
- DIG 2-CH OUTPUT

AES SETTINGS ▼

(IF AES CARD PRESENT)

- SAMPLE RATE IN
- EMPHASIS IN
- EMPHASIS OUT
- MULTI-CHNL TYPE

ADAT SETTINGS ▼

(IF ADAT CARD PRESENT)

- ADAT IN CLOCK
- ADAT IN WIDTH
- ADAT IN SMPL PT
- ADAT OUT WIDTH
- ADAT OUT USERBIT
- FACTORY DEFAULTS

TDIF SETTINGS ▼

(IF TDIF CARD PRESENT)

- IN SAMPLE POINT

SAMPLE RATE IN ▼

- EMPHASIS IN
- EMPHASIS OUT
- CARD TYPE

MADI SETTINGS ▼

(IF MADI CARD PRESENT)

- SAMPLE RATE IN
- EMPHASIS IN
- EMPHASIS OUT
- LEGACY MODE (96K)
- INTERLACE (48CH)
- COAX/OPTICAL IN

FILE MENU ▼

- BACKUP
- RESTORE

- EXPORT
- IMPORT

- FLATTEN PROJECTS
- FILE MANAGEMENT

- MAKE DVDCD IMAGE
- BURN DATA CD/DVD

- BURN AUDIO CD
- FINALIZE CD

- DEL IMG FILE
- MACROS

- MIX AUTOMATION
- FILE PREFS ▼

- SHOW SIZE

- EXPORT FORMAT
- FILL SILENCE

- REFORMAT QUALITY
- WRITE VERIFY

FILE MENU (con't) ▼

FILE NAME FORMAT ▼

PRESET ▼

- TRK-NAME-STAMP
- TRK-PROJ-STAMP
- TRK-REGION-NAME
- TRK-REGION-PROJ
- PROJ-TRK-REGION
- TRK-REGION (DOS)

CUSTOM ▼

- SELECT TEMPLATE
- MAKE TEMPLATE
- IMPORT TEMPLATE
- EXPORT TEMPLATE
- EDIT TEMPLATE
- DELETE TEMPLATE

- DVD BURN MODE
- DVD BURN SPEED

PROJECT MENU ▼

- GOTO PROJECT
- NEW PROJECT
- COPY PROJECT
- DELETE PROJECT
- NAME PROJECT
- RENUMBER PROJECT
- SAMPLE RATE
- BIT RESOLUTION
- TC FORMAT
- TC RATE

- START TIME
- SYNC OFFSET
- DISPLAY MODE

- MIDI TEMPO MAP
- VARISPEED
- UNDO LEVEL

- WAVE NOISE FLOOR
- NAME TRACK
- RENUMBER LOCATES

- REBUILD WAVES
- I/O ROUTING ▼

- INPUT ROUTING
- OUTPUT ROUTING
- RESET ROUTING
- DIG 2-CH ROUTING
- DIGITAL INPUTS
- 8-BUS MODE

- PROJECT NOTES
- PROJECT PREFS ▼

- NEW PROJ SETTINGS
- NEW PROJ NUMBER

- DEF SAMPLE RATE
- DEF BIT RES
- DEF TC FORMAT

- DEF TC RATE
- DEF START TIME
- DEF UNDO LEVEL

- DEF WAVE NS FLR
- TEMPLATE MENU ▼

- MAKE TEMPLATE
- IMPORT TEMPLATE

- EXPORT TEMPLATE
- DELETE TEMPLATE

EDIT MENU ▼

- UNDO EDIT
- REDO EDIT
- MODIFY EDIT
- CUT
- COPY
- PASTE
- MOVE
- ERASE

EDIT MENU (con't) ▼

- LOOP
- SLIDE
- INSERT SILENCE
- REVERSE
- GAIN/FADE
- LISTEN
- EDIT XFADE TIME
- REC XFADE TIME
- CROSSFADE TYPE
- MUTE TRACKS
- RECORD SAFE

PREFERENCES MENU ▼

- DEF SMPTE FIELD
- SHOW SUBFRAMES
- SCROLL PROJ LED
- TRACK SOLO MODE
- ZOOM SOLO AUDIO
- SLIDE TIME UNITS
- FFWD & REW RATE
- MAX JOG RATE
- PEAK HOLD TIME
- CLIP HOLD TIME
- SAVE STATE DELAY

SCRN-SAVER MENU ▼

- SAVER DELAY
- IMAGE EFFECTS
- AUTO RECLAIM
- TRK ARM GROUPING
- IGNORE AES FLAGS
- UNMOUNT PORTABLE
- RADARVIEW RES
- CLOCK MODE
- MUTE I/O ON STOP
- ARROW KEY GOTO
- STOP AT LOCATE
- ASSIGN FT-SWITCH
- ASSIGN MM LOC

RECORD PREFS ▼

- 1-BUTTON RECORD
- TRACK ARM ACTION
- RECORD MK IN/OUT
- LOW DISK WARNING
- RECORD VERIFY
- RECORD ON CHASE
- PROJECT PER TAKE
- RECORD RECOVERY

FILE PREFS ▼

- SHOW SIZE
- EXPORT FORMAT
- FILL SILENCE
- REFORMAT QUALITY
- WRITE VERIFY

FILE NAME FORMAT ▼

- PRESET ▼
- TRK-NAME-STAMP
- TRK-PROJ-STAMP
- TRK-REGION-NAME
- TRK-REGION-PROJ
- PROJ-TRK-REGION
- TRK-REGION (DOS)

CUSTOM ▼

- SELECT TEMPLATE
- MAKE TEMPLATE
- IMPORT TEMPLATE
- EXPORT TEMPLATE
- EDIT TEMPLATE
- DELETE TEMPLATE

- DVD BURN SPEED
- DVD BURN MODE

PREFERENCES MENU (con't) ▼

PROJECT PREFS ▼

- NEW PROJ SETTINGS
- NEW PROJ NUMBER
- DEF SAMPLE RATE
- DEF BIT RES
- DEF TC FORMAT
- DEF TC RATE
- DEF START TIME
- DEF UNDO LEVEL
- DEF WAVE NS FLR

NETWORK PREFS ▼

- INTERFACE PREFS ▼
- HOST NAME
- DHCP SERVER
- LOCAL IP ADDRESS
- SUBNET MASK
- GATEWAY
- PRIMARY DNS
- SECONDARY DNS
- FTP SERVER
- FTP LOGIN NAME
- FTP PASSWORD

SERVER PREFS ▼

- NETWORK PROTOCOL
- SERVER IP ADDR
- SERVER NAME
- SERVER SHARE
- CLIENT WORKGROUP

EMAIL PREFS ▼

- COMPANY NAME
- LOCATION
- REPLY EMAIL
- NETWORK CONTROL

REMOTE PREFS ▼

- COM1, COM2, BOTH

DIAGNOSTICS MENU ▼








- SCAN SCSI BUS
- INIT DISK
- CHECK DISK
- REPAIR DISK
- CHECK PROJECT
- REALTIME ERRORS
- VERIFY DISKS
- SHOW AUDIO LEVEL
- PING IP ADDRESS
- CONFIGURE DEBUG
- SAVE DEBUG
- EMAIL DEBUG
- RESTART DESKTOP
- FACTORY SETTINGS
- INSTALL PREV VER




HELP MENU ▼

- RELEASE NOTES
- MANUAL

SHUTDOWN RADAR



ACTION	KC24	SESSION CONTROLLER
Cycle Through Menu Selections that Start with a Specific Letter	QWERTY key with the first letter	QWERTY key with the first letter
Locate to Start/End of an Audio Region (Use Solo to Isolate Track)	RECALL LOC +  or 	RECALL LOC +  or 
Locate to Mark In Point		
Locate to Mark Out Point		
Locate to Mark Sync Point		
Audition Audio Between Mark In/Out Points		
Locate to Mark Locates	Numeric Keypad (NK)	Numeric Keypad (NK)
Locate to Project Start Time	0 on (NK)	0 on (NK)
Reverse Play	 + PLAY 	 + PLAY 
2X Fast Forward	 Twice Rapidly	 Twice Rapidly
Vertical Zoom	V + + or V + -	VERT ZOOM IN & VERT ZOOM OUT
Horizontal Zoom	Z + + or Z + -	HORZ ZOOM IN & HORZ ZOOM OUT

ACTION	KC24	SESSION CONTROLLER
Check Record Time Remaining	 + 	 + 
Browse Disks	SHIFT + B	SHIFT + B
Available Space on Disk (While browsing)	SPACE	SPACEBAR
Start RADARLink	L	L or RLINK
RADARLink Solo	S	S or RLINK SOLO
Help Menu	H	H or HELP
Name Track	N	N or NAME TRACK
Mute Track	M	M
Clear Clipped Meters	SHIFT + CANCEL	SHIFT + CANCEL
Screen Saver Lock	SHIFT + S	SHIFT + S
Toggle Between: Debug & Waveform View	SHIFT + BACKSPACE	SHIFT + BACKSPACE
Screen Capture	SHIFT + X	SHIFT + X

