

SYSTEM MENU ▼

SYSTEM INFO ▼

- RADAR SOFTWARE VER
- SERIAL NUMBER
- RECORDING ENGINE
- SYNC ENGINE
- INSTALLED RAM
- CPU TYPE
- CPU SPEED
- IP ADDRESS
- MAC ADDRESS
- ETHERNET TYPE
- ANALOG I/O
- DIGITAL I/O 1
- DIGITAL I/O 2
- DIGITAL I/O 3
- IDE 0 MASTER
- IDE 1 MASTER
- SCSI ID 0
- SET TIME & DATE
- SET SERIAL NUM
- UPDATE SOFTWARE

DISK MENU ▼

- MOUNT/UNMOUNT
- SHOW DISK SPACE
- RECLAIM SPACE
- MAKE PORTABLE
- ERASE ALL AUDIO
- INIT DISK
- DISK MODE
- 24 TRKS AT 192K
- SEAMLESS 64K
- CLONE RADAR DISK
- DISK NOTES
- ENABLE DISK ID

SYNC MENU ▼

TC SETTINGS ▼

- TC FORMAT
- TC RATE
- SMPTE LOCK SPEED
- FREEWHEEL TIME
- STATIC TC OUT
- CHASE MODE
- SHOW SYNC DRIFT
- SYNC THRESHOLD
- CHASE ON POWERUP
- SYNC REFERENCE

RADARLINK ▼

- ENABLE/DISABLE
- RADARLINK SOLO
- RADARLINK ID

MACHINE CONTROL ▼

- ENABLE/DISABLE
- SELECT TYPE
- 9-PIN SETTINGS ▼
- DEVICE ID
- 9-PIN CHASE MODE
- TRACK ARM MODE
- VARISPEED MODE
- SHUTTLE-0 MODE
- TC OUT MODE-CUE
- TC OUT MODE-PLAY

MMC SETTINGS ▼

- DEVICE ID
- SYNC REF OUTPUT
- LOST SYNC IN REC

I/O MENU ▼

I/O ROUTING ▼

- INPUT ROUTING
- OUTPUT ROUTING
- RESET ROUTING
- DIG 2-CH ROUTING
- DIGITAL INPUTS
- 8-BUS MODE

- ANALOG I/O LEVEL

- DIG IN FORMAT

- DIG I/O SDQ

- DIG 2-CH OUTPUT

AES SETTINGS ▼

- (IF AES CARD PRESENT)

- SAMPLE RATE IN

- EMPHASIS IN

- EMPHASIS OUT

- MULTI-CHNL TYPE

ADAT SETTINGS ▼

- (IF ADAT CARD PRESENT)

- ADAT IN CLOCK

- ADAT IN WIDTH

- ADAT IN SMPL PT

- ADAT OUT WIDTH

- ADAT OUT USERBIT

- FACTORY DEFAULTS

TDIF SETTINGS ▼

- (IF TDIF CARD PRESENT)

- IN SAMPLE POINT

SAMPLE RATE IN ▼

- EMPHASIS IN

- EMPHASIS OUT

- CARD TYPE

MADI SETTINGS ▼

- (IF MADI CARD PRESENT)

- SAMPLE RATE IN

- EMPHASIS IN

- EMPHASIS OUT

- LEGACY MODE (96K)

- INTERLACE (48CH)

- COAX/OPTICAL IN

- INSTALL FIREWARE

FILE MENU ▼

- BACKUP

- RESTORE

- EXPORT

- IMPORT

- FLATTEN PROJECTS

- FILE MANAGEMENT

- MAKE DVDCD IMAGE

- BURN DATA CD/DVD

- BURN AUDIO CD

- FINALIZE CD

- DEL IMG FILE

- MACROS

- MIX AUTOMATION

FILE PREFS ▼

- SHOW SIZE

- IMPRT PROJ START

- EXPORT FORMAT

- FILL SILENCE

- REFORMAT QUALITY

- WRITE VERIFY

FILE MENU (con't) ▼

FILE NAME FORMAT ▼

PRESET ▼

- TRK-NAME-STAMP

- TRK-PROJ-STAMP

- TRK-REGION-NAME

- TRK-REGION-PROJ

- PROJ-TRK-REGION

- TRK-REGION (DOS)

CUSTOM ▼

- SELECT TEMPLATE

- MAKE TEMPLATE

- IMPORT TEMPLATE

- EXPORT TEMPLATE

- EDIT TEMPLATE

- DELETE TEMPLATE

- DVD BURN MODE

- DVD BURN SPEED

PROJECT MENU ▼

- GOTO PROJECT

- NEW PROJECT

- COPY PROJECT

- DELETE PROJECT

- NAME PROJECT

- RENUMBER PROJECT

- SAMPLE RATE

- BIT RESOLUTION

- TC FORMAT

- TC RATE

- START TIME

- SYNC OFFSET

- DISPLAY MODE

- MIDI TEMPO MAP

- VARISPEED

- UNDO LEVEL

- STOP AT LOCATE

- WAVE NOISE FLOOR

- NAME TRACK

- RENUMBER LOCATES

- REBUILD WAVES

I/O ROUTING ▼

- INPUT ROUTING

- OUTPUT ROUTING

- RESET ROUTING

- DIG 2-CH ROUTING

- DIGITAL INPUTS

- 8-BUS MODE

- PROJECT NOTES

PROJECT PREFS ▼

- NEW PROJ SETTINGS

- NEW PROJ NUMBER

- DEF SAMPLE RATE

- DEF BIT RES

- DEF TC FORMAT

- DEF TC RATE

- DEF START TIME

- DEF UNDO LEVEL

- DEF WAVE NS FLR

TEMPLATE MENU ▼

- MAKE TEMPLATE

- IMPORT TEMPLATE

- EXPORT TEMPLATE

- DELETE TEMPLATE

EDIT MENU ▼

- UNDO EDIT

- REDO EDIT

- MODIFY EDIT

- CUT

- COPY

- PASTE

- MOVE

- ERASE

EDIT MENU (con't) ▼

- LOOP

- SLIDE

- INSERT SILENCE

- REVERSE

- GAIN/FADE

- LISTEN

- EDIT XFADE TIME

- REC XFADE TIME

- CROSSFADE TYPE

- MUTE TRACKS

- RECORD SAFE

PREFERENCES MENU ▼

- DEF SMPTE FIELD

- SHOW SUBFRAMES

- SCROLL PROJ LED

- TRACK SOLO MODE

- ZOOM SOLO AUDIO

- SLIDE TIME UNITS

- FFWD & REW RATE

- MAX JOG RATE

- PEAK HOLD TIME

- CLIP HOLD TIME

- SAVE STATE DELAY

SCRN-SAVER MENU ▼

- SAVER DELAY

- IMAGE EFFECTS

- AUTO RECLAIM

- TRK ARM GROUPING

- IGNORE AES FLAGS

- UNMOUNT PORTABLE

- RADARVIEW RES

- CLOCK MODE

- MUTE I/O ON STOP

- ARROW KEY GOTO

- ASSIGN FT-SWITCH

- ASSIGN MM LOC

RECORD PREFS ▼

- 1-BUTTON RECORD

- TRACK ARM ACTION

- RECORD MK IN/OUT

- LOW DISK WARNING

- RECORD VERIFY

- RECORD ON CHASE

- PROJECT PER TAKE

- RECORD RECOVERY

FILE PREFS ▼

- SHOW SIZE

- IMPRT PROJ START

- EXPORT FORMAT

- FILL SILENCE

- REFORMAT QUALITY

- WRITE VERIFY

FILE NAME FORMAT ▼

PRESET ▼

- TRK-NAME-STAMP

- TRK-PROJ-STAMP

- TRK-REGION-NAME

- TRK-REGION-PROJ

- PROJ-TRK-REGION

- TRK-REGION (DOS)

CUSTOM ▼

- SELECT TEMPLATE

- MAKE TEMPLATE

- IMPORT TEMPLATE

- EXPORT TEMPLATE

- EDIT TEMPLATE

- DELETE TEMPLATE

- DVD BURN SPEED

- DVD BURN MODE

PREFERENCES MENU (con't) ▼

PROJECT PREFS ▼





- NEW PROJ SETTINGS





- NEW PROJ NUMBER

- DEF SAMPLE RATE

- DEF BIT RES

- DEF TC FORMAT

ACTION	KC24	SESSION CONTROLLER
Cycle Through Menu Selections that Start with a Specific Letter	QWERTY key with the first letter	QWERTY key with the first letter
Locate to Start/End of an Audio Region (Use Solo to Isolate Track)	RECALL LOC +  or 	RECALL LOC +  or 
Locate to Mark In Point		
Locate to Mark Out Point		
Locate to Mark Sync Point		
Audition Audio Between Mark In/Out Points		
Locate to Mark Locates	Numeric Keypad (NK)	Numeric Keypad (NK)
Locate to Project Start Time	0 on (NK)	0 on (NK)
Reverse Play	 + PLAY 	 + PLAY 
2X Fast Forward	 Twice Rapidly	 Twice Rapidly
Vertical Zoom	V + + or V + -	VERT ZOOM IN & VERT ZOOM OUT
Horizontal Zoom	Z + + or Z + -	HORZ ZOOM IN & HORZ ZOOM OUT
Enable Disk ID	E	E

ACTION	KC24	SESSION CONTROLLER
Check Record Time Remaining	 + 	 + 
Browse Disks	SHIFT + B	SHIFT + B
Available Space on Disk (While browsing)	SPACE	SPACEBAR
Start RADARLink	L	L or RLINK
RADARLink Solo	S	S or RLINK SOLO
Help Menu	H	H or HELP
Name Track	N	N or NAME TRACK
Mute Track	M	M
Clear Clipped Meters	SHIFT + CANCEL	SHIFT + CANCEL
Screen Saver Lock	SHIFT + S	SHIFT + S
Toggle Between: Debug & Waveform View	SHIFT + BACKSPACE	SHIFT + BACKSPACE
Screen Capture	SHIFT + X	SHIFT + X

