



# IZ TECHNICAL MEMO

## RADAR II AES/EBU PINOUT

Contact iZ Support: (800) 776-1356

Memo Date: January 25, 2001

### AES/EBU card D-Sub 25 pin Female (Input)

Signal	In A	Pin
In 1,2 -		1
In 1,2 +		2
In 3,4 -		3
In 3,4 +		4
In 5,6 -		5
In 5,6 +		6
In 7,8 -		7
In 7,8 +		8
GND		22
GND		23
GND		24
GND		25

Signal	In B	Pin
In 9,10 -		1
In 9,10 +		2
In 11,12 -		3
In 11,12 +		4
In 13,14 -		5
In 13,14 +		6
In 15,16 -		7
In 15,16 +		8
GND		22
GND		23
GND		24
GND		25

Signal	In C	Pin
In 17,18 -		1
In 17,18 +		2
In 19,20 -		3
In 19,20 +		4
In 21,22 -		5
In 21,22 +		6
In 23,24 -		7
In 23,24 +		8
GND		22
GND		23
GND		24
GND		25

Note: Any pins not listed are considered no connect.



# IZ TECHNICAL MEMO

## RADAR II AES/EBU PINOUT

Contact iZ Support: (800) 776-1356

Memo Date: January 25, 2001

### AES/EBU card D-Sub 25 pin Male (Output)

Signal	Out A	Pin
Out 1,2 -		1
Out 1,2 +		2
Out 3,4 -		3
Out 3,4 +		4
Out 5,6 -		5
Out 5,6 +		6
Out 7,8 -		7
Out 7,8 +		8
GND		22
GND		23
GND		24
GND		25

Signal	Out B	Pin
Out 9,10 -		1
Out 9,10 +		2
Out 11,12 -		3
Out 11,12 +		4
Out 13,14 -		5
Out 13,14 +		6
Out 15,16 -		7
Out 15,16 +		8
GND		22
GND		23
GND		24
GND		25

Signal	Out C	Pin
Out 17,18 -		1
Out 17,18 +		2
Out 19,20 -		3
Out 19,20 +		4
Out 21,22 -		5
Out 21,22 +		6
Out 23,24 -		7
Out 23,24 +		8
GND		22
GND		23
GND		24
GND		25

Note: Any pins not listed are considered no connect.